

PROCEAN®

PROLIGHT 3800 I USER MANUAL



SPECIFICATIONS

- Utilize 4*Cree XPL-Hi V3, max 3800 lumens output
- Power by 2*26650 battery, the max runtime can reach 3.5 hours
- Titanium side button for easy operating
- Built-in power indicator under the switch reports the remaining battery power
- Three O-rings design ensure waterproof to 150 meters
- 5mm toughened glass lens can stand higher pressure underwater
- Standard accessories: goodman handle, 3 spare O-rings, lanyard and user manual

TECHNICAL PARAMETERS

ANSI	High	Medium	Low	Strobe
Lumen output	3800 Lumens	/	1300 Lumens	/
Runtime (3*18650)	1.5 hours	/	3.5 hours	/
Luminous Intensity	49000cd			
Beam Distance	442m			
Drop Resistance	1.5m			
Waterproof Grade	IPX-8, underwater 150m			
Dimension	64 (head dia.)*33.93(body dia.)*230.21(length)mm			
Net Weight	423g excluding battery			
Underwater weight	330g including battery			

BATTERY SPECIFICATIONS

- Battery installation
*This lamps needs two battery 2*26650*
Unscrew the tail cap, place the battery with the positive side (+) facing the head of the flashlight.
Screw the tail cap as tight as it can.



PROCEAN®

OPERATION WAYS

- ON/OFF

Press the button to turn on and off the light and changes modes. With the light turn on, press the button way down repeatedly to cycle through the following output: high-low-off. After installing the battery, the flashlight will enter low mode by default and click the head switch to close.

- Lockout/ unlocking

Side switch lockout

When the light is off, the flashlight is locked automatically after 3 minuts. When the light is locked, click the side switch, the indicator of the side switch will flash green to indicate the flashlight is locked.

Side switch unlocking

To unlock the flashlight press and hold the switch for 2 seconds, the flashlight will flash green to indicate the flashlight is locked

- Power tips

When the light is turned on, the built-in power indicator under the switch will perform different status to indicate remaining battery:

Green light - the power is between 100 and 30 %

Red light - the power is between 30 and 10 %

Flashing red light - the power is between 10 and 3 %



GOODMAN HANDLE

- Make the dive lamp fast with the supplied screws
- Unscrew the screw cap on the side
- Move the bar to the desired height
- Tight the screw cap



MAINTENANCE

1. Please immerse the diving light in fresh water for a few minutes after diving every time and dry the flashlight after immersing
2. Please put lubricating oil on the screw threads parts
3. Please don't drop the flashlight into sand, in case the sand goes into the screw parts.
4. Please keep inspecting the O-rings regularly, and change a new one once they are damaged in time
5. Please take the battery out of the light when you store the lamp
6. All the connection parts are all sealed by glue, please do not open the sealed parts

WARNING

The diving light has a high brightness, please DO NOT shine people in the eyes or look at the light directly in case of damaging the eyesight, especially for children.